

930N-5606/STT FLASH PATTERN

LIGHTBAR LAMP CONFIGURATION

DF3	DF2	DF1	PF1	PF2	PF3
DC					PC
DA					PA
DR3	DR2	DR1	PR1	PR2	PR3

MODE	CONTROL WIRES ACTIVATED	LAMP OPERATION	
		REAR / ALLEY STROBES	FRONT / CORNER STROBES
1	ORG	DR3 & PR3 SIMULTANEOUS AND ALTERNATE WITH DR1 & PR1 SIMULTANEOUS (6 PULSES PER BURST) DR2 ALTERNATES WITH PR2 (3 PULSES PER BURST) DA ALTERNATES WITH PA (3 PULSES PER BURST)	NONE
2	ORG & BLU	SAME AS MODE 1	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH *DF1 & *PF1 SIMULTANEOUS (6 PULSES PER BURST)
3	ORG & BLU & WHT/BLK	SAME AS MODE 1	DF3 & PF3 SIMULTANEOUS AND ALTERNATE WITH *DF1 & *PF1 SIMULTANEOUS (6 PULSES PER BURST) DC ALTERNATES WITH PC (3 PULSES PER BURST)

* Optional DF1 and PF1 Strobes

CONTROL WIRES FOR OPTIONAL HALOGENS

CONTROL WIRE ACTIVATED	HALOGEN LAMP
BROWN/WHITE	DF2 & PF2 TAIL LIGHTS
GRAY	DF2 TURN SIGNAL
YELLOW	PF2 TURN SIGNAL
RED/WHITE	DF1 TAKEDOWN
OR	
BRN	PF1 TAKEDOWN
BRN	DR1 & PR1 SPLIT REAR WORK

**NOTE: GREEN control wire activates high intensity to strobes.
Apply +12vdc to appropriate control wire to activate desired function.**